

MTC - MINI TELEMETRY CONTROLLER MTC-COB2 HANDHELD REMOTE

LOW POWER, LICENCE EXEMPT WIRELESS REMOTE CONTROL

The MTC Series is a range of low cost Telemetry Controllers that includes a two button rugged hand held transmitter. The enclosure features a water resistant design, heavy duty buttons and an integrated whip (or helical depending on frequency) antenna. This leaflet details how to replace the internal 3.6V Lithium Thionyl Chloride battery and to apply stickers under the clear button covers.

MTC-COB2 : Transmitter Battery Replacement

- 1. Remove 4 front screws:**



- 2. Replace battery, note the polarity:**



- 3. Replace back cover taking care to ensure the O-ring is seated correctly then refit the 4 front screws:**



MTC-COB2 : Transmitter Button Labelling

- 1. Using a small flat bladed screwdriver, gently prise the clear cover from the button by twisting the screw driver:**



- 2. With the tops removed apply the small round sticker with you own writing on it. Put the covers back in place and gently apply pressure till they click back in place.**



Button Stickers >